

How to measure for a quick price

To get an instant quote all we need are approximate sizes. You can do this by measuring each window or door from inside.

To get the **width** just take a tape and measure from one side of the wall to the other and note down the size in **millimetres** (1 cm = 10mm)

For the **height** measure from the top of the frame down to the bottom of window ledge inside and note down the size in **millimetres** (1cm = 10mm)

Be sure to note down the room in which each window is located.

Make a note of how the current window opens so you can match the same window design.

How to measure for ordering (Only for Collection or Delivery)

If you select our installation service then we will attend site and take accurate measurements for ordering.

If you wish to order and fit the items yourself you will need to provide us with the accurate sizes.

All measurements must be **Metric (mm)** and all styles must be **as viewed from outside**, especially important for hinge positions.

Measure the **width and height of the opening from the outside**; check this dimension at 3 or 4 different points across the frame, checking for any protruding brickwork. **Deduct 10mm** off the smallest measurement, from both the width and height.

If the property is rendered, it is necessary to chip away the render to expose the frame for accurate measurements.

If your **window is to be fitted directly under the soffit** you will need to ensure that the fascia board is not more than **20mm below the soffit**, as it will affect the opening of side hung openings. If it is, go to advanced options and select an add-on for the top

Note that all height measurements must include the cill and any add-on if required. All width measurements must include any add-on required to the sides.